

# "E-WIN" ELECTRONIC LOCK FOR PATIO DOORS AND WINDOWS

## 1) Mounting of the handle

- Remove your old window/patio handle (center measurement 43mm).
- Please measure if the spindle on your old handle is 7x7mm or 8x8mm.
- When the spindle on your old handle measures 8x8mm, you need to slide the adapter over the "E-WIN" spindle.
- Please measure the length of the spindle on your old handle and cut the spindle (with adapter) on your "E-WIN" handle.

## 2) Installation

- Twist the battery cover to the side after removing the hex screw.
- Insert 2 batteries type LS14500. (Do NOT use any other type of battery)
- Insert the battery cover correctly. The tap marked with 2 arrows must match the screw hole in the handle.
- Push the button to active the handle (flashing red 2 times). ●
- Place the master key (big "drop" shaped fob) in front of the button.
- The master key is registered when the button flashes red ● and afterwards blue ●
- Push the button to lock the handle - flashing red ●

## 3) Programming of user keys

- Push the button to activate the handle( flashing red 2 times). ●
- Place the master key (big "drop" shaped fob) in front of the button.
- The button is flashing blue ● and afterwards red. ●
- Place the user key (small "square" shaped fob) in front of the button.
- The user key is registered when the button is flashing purple . ●
- Push the button to lock the handle - flashing red. ●
- Hide the master key somewhere safe. Use it ONLY when you want to program more user keys.
- It's possible to program up to 9 pcs of user keys on each handle (small "square" shaped fob)

#### 4) Deleting User keys

- Push the button to activate then handle (flashing red ● 2 times).
- Place and KEEP the master key (big "drop" shaped fob) in front of the button.
- The button flashes blue, ● afterwards red ● and finally 3 times purple. ●
- All user keys are now deleted from the handle. You cannot delete user keys one by one.
- Push the button to lock the handle - flashing red ●

#### 5) Deleting the Master key

- Push the button to activate the handle (flashing red 2 times). ●
- Place the master key (big "drop" shaped fob) in front of the button.
- The button flashes red ● and afterwards blue ●
- Place and hold the master key (big "drop" shaped fob) in front of the button.
- Keep the master key in front of the button, till the button flashes purple 10 times ●
- Remove the master key away from the button.
- The master key has now been deleted.
- Push the button to lock the handle - flashing red ●

#### 6) When installing several "E-WIN" handles with same master key

- Push the button to activate the handle (flashing red 2 times). ●
- Place the previous installed master key (from your first handle) in front of the button.
- The master key is registered when the button flashes red ● and afterwards blue ●
- Push the button to lock the handle - flashing red ●
- Now you can continue programming more users by following section 3 in this user guide.
- By following the above steps, you can continue programming the master key into more handles.
- For programming more user keys follow section 3 in this user guide.

#### 7) Daily usage of the handle after installation of master key and user key

- Push the button to activate the handle (flashing red 2 times). ●
- Place the user key (small "square" shaped fob) in front of the button.
- The button flashes red ● and afterwards blue ●
- Then handle can now be turned/opened.
- To lock the handle you HAVE to push the button again - flashing red. ● If you do NOT push the button the window/patio door will not be locked.
- Do NOT use the master key on a daily basis. Use the master key ONLY when you need to program further user keys.